



## SECRETLAB 4D FULL-METAL ARMREST (2020) PU PORTION REPLACEMENT GUIDE

---

This guide is designed to assist with the replacement of the top PU portion of the Secretlab 4D Full-Metal Armrest (2020).

### Tools Required:

- Secretlab Armrest PU Replacement Kit, consisting of
  - 1x Armrest PU replacement part
  - 1x flathead screwdriver
- 1x Phillips head screwdriver

## INSTRUCTIONS

1. Use a Phillips head screwdriver to remove the screw located beneath the armrest. Take care not to misplace the screw as it will be re-used at a later step.



2. Insert the provided flathead screwdriver horizontally into the cut-out as pictured, and push upward to lift it from the cut-out.



3. Firmly pull the edges of the PU portion upwards from the armrest.



4. Position the replacement PU portion over the top of the armrest, and push down around the edges of the armrest. You should feel it snap into place securely.



5. Insert the screw that was removed at Step 1 into the screw hole at the bottom of the armrest and tighten fully.



**The armrest PU portion replacement procedure is complete.**

